

Naturatex– Pre-mixed Step by Step

Step 1 Apply Naturatrim corner beads using Shieldflex 1000

Step 2 Apply Naturatape and Naturapatch Coarse to joints feather out flush and smooth with sponge.

Step 3
Apply 1 coat of Alfresco Graincoat polymer texture to entire surface.
Using a Trowel
Mesh may be embedded if applying to Foam boards for impact coat

Step 4

Apply 2nd coat of Alfresco Graincoat polymer texture to entire surface.
Using a Trowel.

Step 5

Float Alfresco Graincoat smooth using a Plastic Float. If texture has not been tinted, you can apply our textureshield Paint, tinted to colour of choice.

Note:

Provencal Sand (applied by roller or brush) may also be used as first coat, second coat alfresco graincoat

Note:

When going over brick you will need a coat of Daudeat highbuild (trowelled), then one coat of your choice of finishes. Graincoat, (Trowelled) paint or provencal sand. (brushed or rolled)

